

For information on other available audio systems or the CD changer system, please refer to your Owner's Guide.

<b>01 AM/FM SELECT</b> In radio mode, press to select the AM or FM1 or FM2 frequency bands.	<b>06 SETTING THE CLOCK</b> Press and hold the H control to set the hour. Press and hold the M control to set the minute.
<b>02 VOLUME/POWER CONTROL</b> Press the control to turn the audio system on or off. Turn the control to raise or lower the volume.	<b>07 TAPE SELECT</b> To begin tape play while in radio mode, press the tape control.
<b>03 SEEK FUNCTION</b> In radio mode, press to find the next listenable station up or down the band. In tape mode, press to move to the next/previous selection on the tape.	<b>08 DOLBY® NOISE REDUCTION</b> Press to activate the system, which reduces tape noise and hiss while playing a tape. Press again to deactivate.

<b>01 AM/FM SELECT</b> In radio mode, press to select the AM/FM1/FM2 frequency bands.	<b>06 SETTING THE CLOCK</b> Press and hold the H control to set the hour. Press and hold the M control to set the minute.
<b>02 VOLUME/POWER CONTROL</b> Press the control to turn the audio system on or off. Turn the control to raise or lower the volume.	<b>07 CD SELECT</b> To begin CD play while in radio mode, press the CD control.
<b>03 SEEK FUNCTION</b> In radio mode, press to find the next listenable station up or down the band. In CD mode, press to move to the next/previous selection on the CD.	<b>08 COMPRESSION</b> Press to bring soft and loud passages together for a more consistent listening level.
<b>04 EJECT</b> Press to eject a CD.	<b>09 SHUFFLE</b> Press to play CD tracks in random order.
<b>05 TUNE ADJUST</b> In radio mode, press to move to the next frequency up or down the band.	<b>10 SCAN FUNCTION</b> In radio mode, press to hear a sampling of all listenable stations. In CD mode press to hear a brief sampling of all selections.

## ESSENTIAL INFORMATION

**ROADSIDE ASSISTANCE**

To fully assist if you should have a vehicle concern, Ford Motor Company offers a complimentary roadside assistance program. This program is separate from the New Vehicle Limited Warranty. The service is available: 24 hours, 7 days a week for the New Vehicle Limited Warranty period of three years or 36,000 miles, whichever comes first. Roadside assistance will cover:

Changing a flat tire | Jump-starts | Limited fuel delivery | Lock-out assistance | Towing of your vehicle

**ROADSIDE ASSISTANCE CENTERS**

United States: (800) 241-3673 | Canada: (800) 665-2006

For complete details on any roadside assistance concern, see the Roadside Emergencies section or the Customer Assistance section in your Owner's Guide.

**REAR WINDOW WIPER & WASHER (Wagon Only)**

The rear wiper and washer control is located under the headlamp controls. Press the wiper control to activate the rear wiper. Press again to turn off the wiper. Press the washer control to activate the rear washer.

**02 INFO BUTTON**  
This feature shows the following control displays:

Odometer | Distance to Empty | Average Fuel Economy  
Trip Odometer | Trip Elapsed Drive Time | Compass (if equipped) | Outside air temperature (if equipped)

For a more detailed description of the INFO controls, please refer to your Owner's Guide.

**03 RESET BUTTON**  
Press this control to select and reset functions shown in the INFO menu and SETUP menu.

For a more detailed description of the RESET control, please refer to your Owner's Guide.

**SYSTEM WARNINGS**

System warnings alert you to possible problems or malfunctions in your vehicle operating systems.

In the event of a multiple warning situation, the message center will cycle the display to show all warnings by displaying each one for several seconds.

The message center will display the last selected feature if there are no more warning messages. This allows you to use the full functionality of the message center after you acknowledge the warning by pressing the RESET control and clearing the warning message.

If any warning stays on or continues to come on, contact your dealer as soon as possible. For a more detailed description of system warnings please refer to your Owner's Guide.


**01 SET BUTTON**  
Setup menu controls the following displays:

Language | Units (English Metric) | System Check

For a more detailed description of the Setup menu, please refer to your Owner's Guide.

## COMPASS (If Equipped)

The compass reading may be affected when you drive near large buildings, bridges, power lines and powerful broadcast antennas. Magnetic or metallic objects placed in, on or near the vehicle may also affect compass accuracy. Usually, when something affects the compass readings, the compass will correct itself after a few days of operating your vehicle in normal conditions. If the compass still appears to be inaccurate, a manual calibration may be necessary. Refer to Compass zone/calibration adjustment in the Driver Controls chapter of your Owner's Guide.




Ford Motor Company  
Customer Relationship Center  
P.O. Box 6248  
Dearborn, Michigan 48121  
(800) 392-3673

September 2003  
Second Printing  
Quick Reference

Mercury Sable  
Litho in U.S.A.



4F4J-19G217-AB



From the advanced Personal Safety System to the bountiful amenities, every

Sable seeks to provide you with safety, comfort, and enjoyment on the road.

In order to help you fully appreciate the countless features of your new Sable,

we invite you to explore this easy-to-use Quick Reference Guide. Using the

image of the instrument panel located in the center of the guide, locate the fea-

ture you would like to learn more about. Each numbered feature is briefly

described to the left of the instrument panel image. For more information,

please consult your Owner's Guide.



## INTERIOR FEATURES

### 01 HEADLAMP AND PANEL DIMMER CONTROL



Rotate clockwise to the first position to turn on the parking lamps, instrument panel lamps, license plate lamps and tail lamps. Rotate to the second position to also turn on the lowbeam headlamps. Pull control out, when exterior lamps are on, to turn on the fog lamps (if equipped). Rotate counterclockwise to activate autolamp (if equipped), which provides light-sensitive automatic on-off control of the exterior lights and keeps the lights on for a fixed period of time after the ignition is turned OFF. Use the panel dimmer control, located to the right of the headlamp control, to adjust the brightness of the instrument panel during headlamp and parking lamp operation, and to turn on or off the overhead dome lamp.

### 02 TURN SIGNAL, HIGH BEAM & WIPER/WASHER CONTROL



Push down to activate the left turn signal or up to activate the right turn signal. Pull stalk toward you to briefly flash the high beams. Push stalk away from you to turn on the headlamp high beams.

Rotate the end of the control away from you to increase or toward you to decrease the speed of the wipers. Pushing the end of the stalk briefly causes a single swipe (no wash). Push and hold to activate the washer.

For extended wiper blade quality, occasional cleaning of the wiper blades is required.

### 03 SERVICE ENGINE SOON WARNING LAMP



This lamp momentarily illuminates to ensure the system is functional. If the light comes on after the engine is started, refer to your Owner's Guide. To help prevent activation, always secure your fuel cap by turning it clockwise until you hear three clicks.

### 04 POWER ADJUSTABLE FOOT PEDALS (IF EQUIPPED)



Press and hold the rocker control to adjust the accelerator and brake pedals toward you or away from you. Adjust the pedals only when the vehicle is stopped and the gearshift lever is in the P (Park) position. The adjustment allows for approximately three inches of maximum travel.

### 05 HAZARD FLASHER CONTROL



Press to activate the hazard flashers. Press the control again to turn the flashers off.

### 06 ABS WARNING LAMP (IF EQUIPPED)



This lamp illuminates briefly when the ignition is turned to the ON position. If the lamp stays on, does not illuminate or flashes, after the engine is started, seek service immediately. In an emergency, apply continuous force on the brake pedal to prevent wheel lock when braking on slippery surfaces - do not pump your brakes. **Note: It is normal to feel a pedal pulsation or hear a noise when the ABS system is activated.**

### 07 TRACTION CONTROL (IF EQUIPPED)




This system helps your vehicle make better use of available traction, especially on slippery road surfaces. The system defaults to ON, however, should you become stuck, try switching the traction control system off. For more information, please consult your Owner's Guide.

### 08 AUXILIARY POWER POINT



Located above the coin holder on the lower portion of the instrument panel, the auxiliary power point is an additional power source for electrical accessories. Improper use of the power outlet can cause damage not covered by your warranty.

### 09 GEARSHIFT/OVERDRIVE CONTROL



Overdrive: D is the normal drive position for the best fuel economy. Switch to the second drive position **D** only when driving with a heavy load, towing a trailer, driving up or down steep hills, or when additional engine braking is desired. This vehicle is equipped with a brake-shift interlock feature that prevents the gearshift lever from being moved from P (Park) when the ignition is in the ON position unless the brake pedal is depressed. If your vehicle is equipped with a console-mounted gearshift lever, you must also press the thumb button on the side of the gearshift lever to move the gearshift lever from P (Park).

### 10 SPEED CONTROL (IF EQUIPPED)



To operate, the speed control must be ON and the vehicle's speed must be at or above 30 mph. To set a speed, press SET/ACC. To set a higher speed, press SET/ACC again, and hold until you reach the desired speed. To set a lower speed, press and hold CST until you reach the desired speed. Pressing RES will return to a previously set speed. To turn the speed control off, press the OFF button or depress the brake pedal to disengage.

### 11 TRUNK RELEASE (IF EQUIPPED)



Press to release the trunk. The control is located on the instrument panel to the left of the steering wheel.

### 12 CHECK FUEL CAP



Illuminates when the fuel cap may not be properly installed. Continued driving with this light on may cause the "SERVICE ENGINE SOON" warning light to come on. Refer to Fuel Filler cap in the Maintenance and Specifications chapter of your Owner's Guide.

Please note that if the fuel cap is not properly installed, "CHECK FUEL CAP" warning may be displayed in the Message Center.

### 13 PASSENGER FRONTAL AIRBAG DEACTIVATION SYSTEM NEW



The "PASSENGER AIRBAG OFF" light will be unlit for properly seated adults (airbag on) or unlit for an empty seat (airbag off). The "PASSENGER AIRBAG OFF" light will be lit (airbag off) for smaller people and properly restrained child safety seats. Even with an automatic on/off system, properly restrain children age 12 and under in the rear seat whenever possible. For additional information on the Passenger Airbag Deactivation System, refer to the Airbags section in the Seating and Safety Restraints chapter of your Owner's Guide.



## ADDITIONAL FEATURES

### REMOTE ENTRY SYSTEM (IF EQUIPPED)



- Press this control once to unlock the driver's door. Press again within 3 seconds to unlock all doors and liftgate (wagon only).
- Press this control once to lock all doors and liftgate (wagon only). Pressing the control a second time within 3 seconds will chirp the horn to confirm that all doors are closed and locked.
- Press this control to activate the panic alarm. To deactivate, press the control again, or turn the ignition to ON.
- Press this control to unlatch the trunk or liftgate (wagon only).

The interior lights will turn on when the remote is used to unlock the doors or sound the panic alarm. The interior lights will turn off if the ignition switch is turned to the ON position, or after 25 seconds of illumination. The dome lamp control must not be set to the OFF position for the illuminated entry system to operate. The remote-control entry features only operate with the ignition in the LOCK position.

### SECURILOCK™ PASSIVE ANTI-THEFT SYSTEM



The SecuriLock passive anti-theft system is an engine immobilization system. This system prevents the engine from being started unless a coded key programmed to your vehicle is used. Please note that for security purposes, your coded keys cannot be copied. If you would like spare coded keys, they can be purchased from your dealership.

### KEYLESS ENTRY SYSTEM (IF EQUIPPED)



With this control you can unlock the trunk/liftgate or lock/unlock the doors without using a key. First, enter your five-digit program code, which will unlock the driver's door only, and then press the corresponding quick key:

- Unlock all doors and the liftgate (wagon only) ..... 3-4
- Unlock the trunk or liftgate (wagon only) ..... 5-6
- Lock all doors ..... 7-8 and 9-0 simultaneously

### SIDE VIEW MIRROR CONTROL



Move the mirror selector control to L to adjust the left mirror, or R to adjust the right mirror. Next, move the mirror control in the direction you wish to tilt the mirror. Return the selector control to the center position to lock the mirrors in place.